PEGASO Quick Start Guide





PEGASO







PEGASO Hose Controls

Preparing the PEGASO Steam Operation:


1. Plug cable into a wall outlet. **NOTE:** Do NOT use multi-outlet power-boards and avoid using low-quality extension cables.

2. Open water tank filler cap (i), fill tank with clean tap water up to the line indicator on the left-side panel (iv) then close filler cap. **NOTE:** Do NOT




use de-mineralised water, do NOT fill above maximum line indicator (iv) and do NOT fill with any chemicals.

3. Turn PEGASO on using the ON/OFF switch (a), making sure



4. Press the 'Boiler Switch' button on the display (c) to start the boiler. After approx. 10 minutes the digital display (b) showing the boiler temperature should show a temperature at or slightly above 170°C and the pressure gauge (p) shows "8 bar". This means that the steam function is ready to use.



MAXIMUM

5. Connect hose to the PEGASO by opening the protective plastic flap located on the front of the machine (v) and pushing the plug end of the hose in with the "doman" imprint on the top side of the hose until it clicks.

Proceed to "Vacuum Operation" and/or "Detergent Operation" section if you are planning on using the vacuum and/or detergent functions together with the steam functions.

Vacuum Operation:

Locate the vacuum switch (S) on the vacuum head unit (iii) and turn it on.

NOTE: The vacuum bucket can be cleaned



by detaching the bucket from the vacuum head through the latch that holds it. Always make sure the bucket is fitted properly to ensure that the contents will not disperse to your surroundings.

Detergent Operation:

Open detergent tank filler cap (ii).
Fill tank with the diluted 101 degreaser

solution until it

reaches up to



the line indicator on the right-side panel (vi). **NOTE:** We recommend using Steam Australia's 101 degreaser or similar to ensure it does not impact machine operation and/or cause adverse health issues

3. Replace the detergent filler cap (ii) before operating.

PEGASO Quick Start Guide



Hose Handle Operations

Steam Function:

- 1. After approx. 8-10 minutes, check that the pressure gauge reaches "7.5 bar" and the digital display shows that the boiler temperature reaches at or above 170° C.
- 2. If the PEGASO makes a beeping noise and the "Tank Level" LED (d) flashes, proceed to Step 2 of "Preparing the PEGASO | Steam Operations" (page 1).
- 3. For S/V Hose, press and hold the trigger (T) to activate the steam function. For S/O Hose, toggle the steam on/off switch (h) to activate an automatic stream.
- 4. Adjust the steam level from the knob (e). Turning counter-clockwise will increase steam level, turning clockwise will decrease it.

WARNING: Do NOT operate hose with steam nozzle pointing at persons, animals or electrical machinery /equipment/outlets/sensors that are sensitive to water and heat (especially near fire alarm sensors).

Vacuum Function:

- 1. Plug the S/V Hose to the PEGASO.
- 2. Press the vacuum button (f) to engage the vacuum function. The vacuum will turn on and you will feel suction from the vacuum nozzle.

NOTE: Ensure that you regularly empty out the contents of the vacuum waste bucket for a smooth operation and clean the HEPA filter located under the vacuum head inside of the bucket if it is very stained. Use soapy warm water to wash the HEPA filter, rinse and let dry before re-installing.

Detergent Function:

Press and hold the detergent button ((g) for S/V Hose, (k) for S/O Hose) to activate the detergent function.

If the detergent runs low in the PEGASO, the hoses will stop spraying detergent. This is noticeable when using the steam function in conjunction with the detergent function as only the drier steam sprays out the nozzle when the detergent function is activated.

Proceed to Step 1-3 of "Preparing the PEGASO | Detergent Operation" (page 1) if this happens.

Warning Lights

The PEGASO will make a beeping noise and a red LED light will flash when the water tank's level is low:



For water tank low level, refer to Step 2 of "Preparing the PEGASO | Steam Operations" (page 1).

Cleaning the PEGASO

Draining the PEGASO's boiler once a month ensures that the machine operates at optimal performance.

WARNING: Ensure machine has cooled down before attempting to clean out the boiler by checking that the machine doesn't feel warm on the bottom part and machine is free from any pressure.

You will need:

- A pan or container that can hold at least 5 litres of water
- A rag
- 8mm Allen Key
- 1. Ensure the machine isn't plugged into a power source and the machine doesn't feel warm (no pressure present).
- 2. Locate the stainless steel boiler plug underneath the PEGASO and position the PEGASO on top of a pan or container.
- 3. Using the 8mm Allen key, unscrew the boiler plug by slowly turning counter-clockwise. You may need to use a rag to hold the plug as you unscrew the plug by hand after loosening using the socket wrench. Let the water drain, then screw the plug back on and tighten with supplied socket wrench.



Floor Tool (Steam + Vacuum)











KIT0824 Rubber Lip Insert

> 2 x KIT0801 Extension Tube S/V 500mm

KIT0800/MOD S/V Hose 4M For hard floor surfaces such as:

- Tiles
- Marble
- Most sealed hardwood
- Linoleum & Vinyl
- Carpets
- Non-slip surfaces

First, use high steam pressure to lift dirt off the floor. Then disengage the steam and turn on the vacuum to suck the floor dry.

We recommend using the steam and vacuum functions separately as it will perform better this way. Whenever the vacuum motor is turned on, the steam boiler loses some of its power and will take longer to produce 7.5 bars of pressure.

Triangular Brush (Steam Only)





KIT0709 Triangular Brush with bristles



KIT0706 Joint for brushes



KIT0700 S/O Hose 4M



Microfibre Cloth

For cleaning skirting boards, kitchen benchtops, underneath kitchen cabinets, rangehoods, car interior and other areas.

Wrap the triangular brush with a microfibre cloth to steam clean upholstery and other surfaces.



Detailing Extension (Steam Only)





For cleaning and sanitizing areas such as:

- Sinks
- Toilets
- Car interior & exterior
- Hard to reach nooks & crannies

This tool is also available for the **KIT0800/MOD** Steam + Vacuum hose:

KIT0808/DA/X – S/V lance short KIT0808/DA350/X – S/V lance long 350mm

Squeegee (Steam Only)





KIT0711 Steam Squeegee

Spray a stream of steam in a circular motion onto the glass surface, then use the rubber squeegee part to remove water condensation and clean the surface.

If using in areas with frosty climates, warm the windows or mirrors by spraying a high stream of steam for a slightly prolonged time before cleaning.

This tool is also available for the **KIT0800/MOD** Steam + Vacuum Hose:

KIT0805 S/V Squeegee 300mm



Detailing Extension + Small Nylon Brush (Steam Only)







KIT0703 Steam Lance 100mm



2 x KIT0701 S/O Extension Tube 500mm



KIT0700 S/O Hose 4M



KIT0816/N Small Brush w/ nylon bristles



KIT0816/I Small Brush w/ Stainless Steel bristles

Optional Accessories:



KIT0816/O Small Brush w/ Brass bristles



KIT0814/O Big Round Brush w/ Brass bristles For detail cleaning in kitchens, bathrooms and other areas:

- Tile grouts (walls and floors)
- Drains
- Cooktops
- Bathtubs
- Roadside chewing gum removal

For best results, hold brush on angle to clean sides of the grout line, and then tilt in other direction to clean the other side of the grout line.

Optional stainless steel and/or brass brushes can be fitted onto the detailing nozzle to scrub off certain hard-to-remove stains in nooks and crannies. Stainless steel is particularly effective on grout and chewing gum stains.

Be wary that the stainless steel and brass brushes may scratch certain surfaces, leaving unwanted scratch marks. Always test areas in an inconspicuous spot before proceeding.

This tool is also available for the **KIT0800/MOD** Steam + Vacuum hose:

KIT0808/DA/X – S/V lance short KIT0801 – Extension Tube S/V 500mm

The brushes fits both S/V and S/O lances.



Floor Mop Head + Microfibre Mop Pad (Steam Only)



Car Wash Upholstery Tool (Steam + Vacuum) (Optional Tool)

